


# PARTS LIST

- 1A - Servo Holder x 8
- 1B - Servo Mount x 4
- 2 - Twist Shaft x 2
- 3A - Leg Link x 12
- 3B - Servo Leg Link x 4
- 4 - Cross Brace x 8
- 5 - Foot x 2
- 6 - Head Base x 1
- 7 - Head Face x 1
- 8 - Side Panel x 2
- 9A - Left Eye x 1
- 9B - Right Eye x 1
- 10 - Arm Gear x 2
- 11 - Arm x 2
- 12 - Hand x 2
- 14 - Arm Servo Gear x 2
- Eye Cup Washer x 1
- Foot Spring x 2
- Power Cable x 1
- On/Off Switch x 1
- Battery x 1
- Leg Twist Servo x 2
- Hip/Knee Servo x 2
- Arm/Eye Servo x 3
- Servo Horn x 3
- Bolt (2.5x8mm) x 51
- Bolt (2x10mm) x 10
- Servo Horn Screw x 3
- Nut (2.5mm) x 51
- Nut (2mm) x 10
- Rick x 1
- Charging Cable x 1
- Bump Switch x 1
- Sticker Pack x 1

## ELECTRONIC COMPONENTS



## NUTS, BOLTS & SCREWS



## BODY PARTS

