



Safety Warnings

- Please retain this safety information, all instructions, leaflets and Marty's packaging for future reference as they contain important safety information.
- Marty is not a toy, adult supervision is required at all times.
- Marty contains small parts which may present a choking hazard - not suitable for children under the age of 10.
- Do not expose Marty to extreme heat or a naked flame.
- Battery must be charged with the supplied charger only. Never use a modified or damaged charger.
- Do not reverse the polarity of the battery terminals or try to force the charger and battery connectors together in a way that is not intended.
- The charging cable and the battery are not toys.
- Avoid excessive physical shock or vibration.
- Do not immerse Marty or any of Marty's components in water and do not use in an environment where there is a possibility of getting Marty wet.
- Do not disassemble, deform, puncture, short circuit, modify in any way or heat the battery. Improper use can result in fire causing serious injury and property damage.
- Stop using Marty and disconnect the battery immediately if the battery begins to bulge or becomes hot.
- Chargers used with Marty are to be regularly examined for damage to the cord, plug, enclosure and other parts. In the event of such damage, Marty must not be used with the charger until the damage has been repaired.
- Never exceed the battery's maximum rated discharge current or charge rate.
- Never leave Marty charging unattended. Do not charge Marty for more than 24 hours.
- Only use Marty with the supplied rechargeable battery. Rechargeable batteries are only to be charged under adult supervision. Non-rechargeable batteries are not to be recharged. Batteries are to be inserted with the correct polarity. Please see the instruction manual for details of how to connect the battery with the correct polarity. Please retain the instruction manual for future reference. Exhausted batteries are to be removed from Marty.
- Use the supplied USB charging cable. The charging cable is not a toy. Connect charging cable to a USB 5v 1.5 A DC supply. If connecting to a transformer, only use Marty with a transformer for toys. The transformer is not a toy.
- Do not clean Marty with liquid.
- Marty is only to be connected to Class II equipment bearing the following symbol when applicable 
- Keep fingers away from Marty when in use to avoid trapping hazards or injury.
- Do not place in mouth, chew or consume any of Marty's components.
- Marty contains a "WiFi" (IEEE 802.11) radio transmitting device. Check with relevant authorities and regulations before use.



Warning!
Choking Hazard - Small Parts
Not for children under 3 years old




MARTY THE ROBOT

Parts Guide

PARTS LIST

- Servo Holder x 8
- Servo Mount x 4
- Twist Shaft x 2
- Leg Link x 12
- Servo Leg Link x 4
- Cross Brace x 8
- Foot x 2
- Head Base x 1
- Head Face x 1
- Side Panel x 2
- Left Eye x 1
- Right Eye x 1
- Arm Gear x 2
- Arm x 2
- Hand x 2
- Arm Servo Gear x 2
- Eye Cup Washer x 1
- Foot Spring x 2
- Power Cable x 1
- ON/OFF Cable x 1
- Li-Ion Battery x 1
- Leg Twist Servo x 2
- Hip/Knee Servo x 4
- Arm/Eye Servo x 3
- Arm/Eye Servo Horn x 3
- Bolt (2.5x8mm) x 51 ≈
- Bolt (2x10mm) x 10 ≈
- Servo Horn Screw x 3 ≈
- Nut (2.5mm) x 51 ≈
- Nut (2mm) x 10 ≈
- Rick x 1
- Charging Cable x 1
- Bump Switches x 2
- Screwdriver x 1

ELECTRONIC COMPONENTS



FIXINGS



BODY PARTS

